


# Easy Touch Controls



## API Documentation

## Table des matières

---

ETCInput .....	4
Static functions for controls .....	7
SetControlVisible .....	7
GetControlVisible .....	9
SetControlActivated .....	10
GetControlActivated .....	11
SetControlSwipeIn .....	12
GetControlSwipeIn .....	13
SetControlSwipeOut .....	14
GetControlSwipeOut .....	15
SetDPadAxesCount .....	16
GetDPadAxesCount .....	17
Static functions for buttons .....	18
GetButtonDown .....	18
GetButton .....	19
GetButtonUp .....	20
GetButtonValue .....	21
Static functions for axes .....	22
GetAxis .....	22
GetAxisSpeed .....	24
GetAxisDownUp .....	25
GetAxisDownRight .....	26
GetAxisDownDown .....	27
GetAxisDownLeft .....	28
GetAxisPressedUp .....	29
GetAxisPressedRight .....	30
GetAxisPressedDown .....	31
GetAxisPressedLeft .....	32
Static functions for axes properties .....	33
SetAxisEnabled .....	34
GetAxisEnabled .....	35
SetAxisInverted .....	36
GetAxisInverted .....	37
SetAxisDeadValue .....	38
GetAxisDeadValue .....	39
SetAxisSensitivity .....	40
GetAxisSensitivity .....	41
SetAxisThreshold .....	42
GetAxisThreshold .....	43
SetAxisInertia .....	44
GetAxisInertia .....	45
SetAxisInertiaSpeed .....	46
GetAxisInertiaSpeed .....	47
SetAxisInertiaThreshold .....	48
GetAxisInertiaThreshold .....	49
SetAxisAutoStabilization .....	50
GetAxisAutoStabilization .....	51

SetAxisAutoStabilizationSpeed .....	52
GetAxisAutoStabilizationSpeed .....	53
SetAxisAutoStabilizationThreshold .....	54
GetAxisAutoStabilizationThreshold .....	55
SetAxisClampRotation .....	56
GetAxisClampRotation .....	57
SetAxisClampRotationValue .....	58
SetAxisClampRotationMinValue .....	59
GetAxisClampRotationMinValue .....	60
SetAxisClampRotationMaxValue .....	61
GetAxisClampRotationMaxValue .....	62
SetAxisDirectTransform .....	63
GetAxisDirectTransform .....	64
SetAxisDirectAction .....	65
GetAxisDirectAction .....	66
SetAxisAffectedAxis .....	67
GetAxisAffectedAxis .....	68
Enumerations .....	69
DirectAction .....	69
DPadAxis .....	69
AxisInfluenced .....	70

## ETCInput

---

# ETCInput

## Description

Interface into the EasyTouch Controls Input system.

Use this class to read/write the axes, buttons, controls.

Axis names are configurable in the inspector and must be unique. The buttons don't have axes, is the name of the button that will be taken into account.

## Static functions for controls

- [SetControlVisible](#) : Set the control identified by ctrlName visible or not.
- [GetControlVisible](#) : Return true if control the identified by ctrlName is visible.
- [SetControlActivated](#) : Set the control identified by ctrlName active or not.
- [GetControlActivated](#) : Return true if control identified by ctrlName is activated.
- [SetControlSwipeIn](#) : Set the control identified by ctrlName to allow swipe in gesture or not.
- [GetControlSwipeIn](#) : Return true if the control identified by ctrlName allows swipe in gesture.
- [SetControlSwipeOut](#) : Set the control identified by ctrlName to allow swipe out gesture or not.
- [GetControlSwipeOut](#) : Return true if the control identified by ctrlName allows swipe out gesture.
- [SetDPadAxesCount](#) : Set the number of axes for the DPad identified by ctrlName.
- [GetDPadAxesCount](#) : Return DPadAxis value for the DPad identified by ctrlName.

## Static functions for buttons

- [GetButtonDown](#) : Returns true during the frame the user pressed down the button identified by buttonName.
- [GetButton](#) : Returns true while the button identified by buttonName is held down.
- [GetButtonUp](#) : Returns true the first frame the user releases the button identified by buttonName.
- [GetButtonValue](#) : Return the value of the button identified by buttonName.

## Static functions for axes

- [GetAxis](#) : Returns the value of the axis identified by axisName.

- [GetAxisSpeed](#) : Returns the speed value of the axis identified by axisName.
- [GetAxisDownUp](#) : Returns true during the frame the user move up the axis identified by axisName.
- [GetAxisDownRight](#) : Returns true during the frame the user move right the axis identified by axisName.
- [GetAxisDownDown](#) : Returns true during the frame the user move down the axis identified by axisName.
- [GetAxisDownLeft](#) : Returns true during the frame the user move left the axis identified by axisName.
- [GetAxisPressedUp](#) : Returns true while the axis identified by axisName is held in up.
- [GetAxisPressedRight](#) : Returns true while the axis identified by axisName is held in right.
- [GetAxisPressedDown](#) : Returns true while the axis identified by axisName is held in down.
- [GetAxisPressedLeft](#) : Returns true while the axis identified by axisName is held in left.

## Static functions for axes properties

- [SetAxisEnabled](#) : Set the axis identified by axisName enabled or not.
- [GetAxisEnabled](#) : Return true if the axis identified by axisName is enabled.
- [SetAxisInverted](#) : Set the axis identified by axisName inverted or not.
- [GetAxisInverted](#) : Return true if the axis identified by axisName is inverted.
- [SetAxisDeadValue](#) : Set the dead value of the axis identified by axisName.
- [GetAxisDeadValue](#) : Return the dead value of the axis identified by axisName.
- [SetAxisSensitivity](#) : Set the sensitivity value of the axis identified by axisName.
- [GetAxisSensitivity](#) : Return the sensitivity value of the axis identified by axisName.
- [SetAxisThreshold](#) : Set the threshold value of the axis identified by axisName.
- [GetAxisThreshold](#) : Return the threshold value of the axis identified by axisName.
- [SetAxisInertia](#) : Set the inertia enabled or not on the axis identified by axisName.
- [GetAxisInertia](#) : Return true if the axis identified by axisName has inertia enabled.
- [SetAxisInertiaSpeed](#) : Set the inertia value of the axis identified by axisName.
- [GetAxisInertiaSpeed](#) : Return the inertia value of the axis identified by axisName.
- [SetAxisInertiaThreshold](#) :Set the inertia threshold value of the axis identified by axisName.
- [GetAxisInertiaThreshold](#) : Return the inertia threshold value of the axis identified by axisName.
- [SetAxisAutoStabilization](#): Set the auto-stabilization enabled or not on the axis identified by axisName.
- [GetAxisAutoStabilization](#): Return true if the axis identified by axisName has auto-stabilization enabled.

[SetAxisAutoStabilizationSpeed](#) : Set the auto-stabilization speed value of the axis identified by axisName.

[GetAxisAutoStabilizationSpeed](#) : Return the auto-stabilization speed value of the axis identified by axisName.

[SetAxisAutoStabilizationThreshold](#): Set the auto-stabilization threshold value of the axis identified by axisName.

[GetAxisAutoStabilizationThreshold](#): Return the auto-stabilization threshold value of the axis identified by axisName.

[SetAxisClampRotation](#) : Set the clamp rotation enabled or not on the axis identified by axisName.

[GetAxisClampRotation](#) : Return true if the axis identified by axisName has clamp rotation enabled.

[SetAxisClampRotationValue](#) : Set the min & max clamp rotation value on the axis identified by axisName.

[SetAxisClampRotationMinValue](#) : Set the min clamp rotation value on the axis identified by axisName.

[GetAxisClampRotationMinValue](#) : Return the min clamp rotation value on the axis identified by axisName.

[SetAxisClampRotationMaxValue](#) : Set the max clamp rotation value on the axis identified by axisName.

[GetAxisClampRotationMaxValue](#) : Return the max clamp rotation value on the axis identified by axisName.

[SetAxisDirecTransform](#) : Set the transform direction action on the axis identified by axisName.

[GetAxisDirectTransform](#) : Return the transform direction action on the axis identified by axisName.

[SetAxisDirectAction](#) : Set the direction action on the axis identified by axisName.

[GetAxisDirectAction](#) : Return the direction action on the axis identified by axisName.

[SetAxisAffectedAxis](#) : Set the axis affected by the direct action on the axis identified by axisName.

[GetAxisAffectedAxis](#) : Return the axis affected by the direct action on the axis identified by axisName.

## Static functions for controls

# ETCInput

## Description

Interface into the EasyTouch Controls Input system.

Use this class to read/write the axes, buttons, controls.

Axis names are configurable in the inspector and must be unique. The buttons don't have axes, is the name of the button that will be taken into account.

## Static functions for controls

- [SetControlVisible](#) : Set the control identified by ctrlName visible or not.
- [GetControlVisible](#) : Return true if control the identified by ctrlName is visible.
- [SetControlActivated](#) : Set the control identified by ctrlName active or not.
- [GetControlActivated](#) : Return true if control identified by ctrlName is activated.
- [SetControlSwipeIn](#) : Set the control identified by ctrlName to allow swipe in gesture or not.
- [GetControlSwipeIn](#) : Return true if the control identified by ctrlName allows swipe in gesture.
- [SetControlSwipeOut](#) : Set the control identified by ctrlName to allow swipe out gesture or not.
- [GetControlSwipeOut](#) : Return true if the control identified by ctrlName allows swipe out gesture.
- [SetDPadAxesCount](#) : Set the number of axes for the DPad identified by ctrlName.
- [GetDPadAxesCount](#) : Return DPadAxis value for the DPad identified by ctrlName.

## SetControlVisible

## ETCInput.SetControlVisible

```
public static void SetControlVisible(string: ctrlName, bool value)
```

## Description

Set the control identified by ctrlName visible or not, relative to value parameter.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {
```

```
void Start() {  
    ETCInput.SetControlVisible("MyJoystick",false);  
}  
}
```

## GetControlVisible

# ETCInput.GetControlVisible

```
public static void GetControlVisible(string: ctrlName)
```

## Description

Return true if control identified by ctrlName is visible.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetControlVisible("MyJoystick")) {
            Debug.Log( "Mys joystick is visible");
        }
    }
}
```

## SetControlActivated

# ETCInput.SetControlActivated

```
public static void SetControlActivated(string: ctrlName, bool value)
```

## Description

Set the control identified by ctrlName active or not, relative to value parameter.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetControlActivated("MyJoystick",true);
    }
}
```

## GetControlActivated

# ETCInput.GetControlActivated

```
public static void GetControlActivated(string: ctrlName)
```

## Description

Return true if control identified by ctrlName is activated.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetControlActivated("MyJoystick")) {
            Debug.Log( "My joystick is activated");
        }
    }
}
```

## SetControlSwipeIn

# ETCInput.SetControlSwipeIn

```
public static void SetControlSwipeIn(string: ctrlName, bool value)
```

## Description

Set the control identified by ctrlName to allow swipein gesture or not, relative to value parameter.

Swipe in allows you to use the control even if the start touch occurs outside the control and slid over him. This behavior is available only for the Touchpad & buttons.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetControlSwipeIn("MyButton", true);
    }
}
```

## GetControlSwipeIn

# ETCInput.GetControlSwipeIn

```
public static void GetControlSwipeIn(string: ctrlName)
```

## Description

Return true if the control identified by ctrlName allows swipein behavior.

Swipe in allows you to use the control even if the start touch occurs outside the control and slid over him. This behavior is available only for the Touchpad & buttons.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetControlSwipeIn("MyButton")) {
            Debug.Log( "My Button has swipein enabled");
        }
    }
}
```

## SetControlSwipeOut

# ETCInput.SetControlSwipeOut

```
public static void SetControlSwipeOut(string: ctrlName, bool value)
```

### Description

Set the control identified by ctrlName to allow swipeout gesture or not relative to value parameter.

Swipe Out allows you to use the control even if the current touch position isn't over him but the touch start occurs over him. This behavior is available only for the Touchpad & buttons.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetControlSwipeOut("MyButton",true);
    }
}
```

## GetControlSwipeOut

# ETCInput.GetControlSwipeOut

```
public static void GetControlSwipeOut(string: ctrlName)
```

### Description

Return true if the control identified by ctrlName allows swipeout behavior.

Swipe in allows you to use the control even if the start touch occurs outside the control and slid over him. This behavior is available only for the Touchpad & buttons.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetControlSwipeOut("MyButton")) {
            Debug.Log( "My Button has swipeOut enabled");
        }
    }
}
```

## SetDPadAxesCount

# ETCInput.SetDPadAxesCount

public static void **SetDPadAxesCount**(string: ctrlName, [ETCBase.DPadAxis](#) value )

## Description

Set the number of axes for the DPad identified by ctrlName relative to value parameter.

The DPad can be used with 2 or 4 axes:

- 2 axes : Up / Down & Left / Right
- 4 axes : Up / Down & Left / Right & Up Left /Right & Down Left/Right

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetDPadAxesCount("MyDPad",ETCBase.DPadAxis.Two_Axis);
    }
}
```

## GetDPadAxesCount

# ETCInput.GetDPadAxesCount

public static [ETCBase.DPadAxis](#) GetDPadAxesCount(string: ctrlName)

## Description

Return DPadAxis value for the DPad identified by ctrlName.

The DPad can be used with 2 or 4 axes:

- 2 axes : Up / Down & Left / Right
- 4 axes : Up / Down & Left / Right & Up Left /Right & Down Left/Right

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetDPadAxesCounr("MyDPad") == ETCBase.DPadAxis.Two_Axis) {
            Debug.Log( "My DPad has 2 axes");
        }
    }
}
```

## Static functions for buttons

# ETCInput

## Description

Interface into the EasyTouch Controls Input system.

Use this class to read/write the axes, buttons, controls.

Axis names are configurable in the inspector and must be unique. The buttons don't have axes, is the name of the button that will be taken into account.

## Static functions for buttons

[GetButtonDown](#) : Returns true during the frame the user pressed down the button identified by `buttonName`.

[GetButton](#) : Returns true while the button identified by `buttonName` is held down.

[GetButtonUp](#) : Returns true the first frame the user releases the button identified by `buttonName`.

[GetButtonValue](#) : Return the value of the button identified by `buttonName`.

## GetButtonDown

## ETCInput.GetButtonDown

```
public static bool GetButtonDown(string: buttonName)
```

## Description

Returns true during the frame the user pressed down the virtual button identified by `buttonName`.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {
    public GameObject projectile;

    void Update() {
        if (ETCInput.GetButtonDown("Fire1")) {
            Instantiate(projectile, transform.position, transform.rotation) as GameObject;
        }
    }
}
```

## GetButton

# ETCInput.GetButton

```
public static bool GetButton(string: buttonName)
```

## Description

Returns true while the button identified by buttonName is held down.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    public GameObject projectile;
    public float fireRate = 0.5F;
    private float nextFire = 0.0F;

    void Update() {
        if (ETCInput.GetButton("Fire1") && Time.time > nextFire) {
            nextFire = Time.time + fireRate;
            Instantiate(projectile, transform.position, transform.rotation) as GameObject;
        }
    }
}
```

## GetButtonUp

# ETCInput.GetButtonUp

```
public static bool GetButtonUp(string: buttonName)
```

### Description

Returns true the first frame the user releases the virtual button identified by buttonName

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    public GameObject projectile;
    public float fireRate = 0.5F;
    private float nextFire = 0.0F;

    void Update() {
        if (ETCInput.GetButtonUp("Fire1") && Time.time > nextFire) {
            nextFire = Time.time + fireRate;
            Instantiate(projectile, transform.position, transform.rotation) as GameObject;
        }
    }
}
```

## GetButtonValue

# ETCInput.GetButtonValue

```
public static float GetButtonUp(string: buttonName)
```

### Description

Return the value of the button identified by buttonName.

Uses this function when your button has over time enabled, to know his value.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    public GameObject projectile;
    public float fireRate = 0.5f;

    void Update() {
        if (ETCInput.GetButtonValue("Fire1") > 0.5f) {
            Instantiate(projectile, transform.position, transform.rotation) as GameObject;
        }
    }
}
```

## Static functions for axes

# ETCInput

## Description

Interface into the EasyTouch Controls Input system.

Use this class to read/write the axes, buttons, controls.

Axis names are configurable in the inspector and must be unique. The buttons don't have axes, is the name of the button that will be taken into account.

## Static functions for axes

- [GetAxis](#) : Returns the value of the axis identified by axisName.
- [GetAxisSpeed](#) : Returns the speed value of the axis identified by axisName.
- [GetAxisDownUp](#) : Returns true during the frame the user move up the axis identified by axisName.
- [GetAxisDownRight](#) : Returns true during the frame the user move right the axis identified by axisName.
- [GetAxisDownDown](#) : Returns true during the frame the user move down the axis identified by axisName.
- [GetAxisDownLeft](#) : Returns true during the frame the user move left the axis identified by axisName.
- [GetAxisPressedUp](#) : Returns true while the axis identified by axisName is held in up.
- [GetAxisPressedRight](#) : Returns true while the axis identified by axisName is held in right.
- [GetAxisPressedDown](#) : Returns true while the axis identified by axisName is held in down.
- [GetAxisPressedLeft](#) : Returns true while the axis identified by axisName is held in left.

## GetAxis

## ETCInput.GetAxis

```
public static float GetAxis(string: axisName)
```

### Description

Returns the value of the virtual axis identified by axisName.

The value will be in the range -1...1 for Joystick, DPad. If the axis belongs to a TouchPad the range is not -1...1, because this function return the delta position.

```
using UnityEngine;
```

```
using System.Collections;

public class ExampleClass : MonoBehaviour {

    public float speed = 10.0F;
    public float rotationSpeed = 100.0F;

    void Update() {
        float translation = ETCInput.GetAxis("Vertical") * speed;
        float rotation = ETCInput.GetAxis("Horizontal") * rotationSpeed;
        translation *= Time.deltaTime;
        rotation *= Time.deltaTime;
        transform.Translate(0, 0, translation);
        transform.Rotate(0, rotation, 0);
    }
}
```

## GetAxisSpeed

# ETCInput.GetAxisSpeed

```
public static float GetAxisSpeed(string: axisName)
```

### Description

Returns the speed value of the virtual axis identified by axisName.

The value will be the equal to =Axis Value \* Axis Sensitivity \* Time.DeltaTime.

Axis Sensitivity = Axis speed for Joystick and DPad on inspector.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        float translation = ETCInput.GetAxisSpeed("Vertical");
        float rotation = ETCInput.GetAxisSpeed("Horizontal");
        transform.Translate(0, 0, translation);
        transform.Rotate(0, rotation, 0);
    }
}
```

## GetAxisDownUp

# ETCInput.GetAxisDownUp

```
public static bool GetAxisDownUp(string: buttonName)
```

### Description

Returns true during the frame the user move up the axis identified by axisName.

For Joystick the value of its axis must be > axis threshold (On / Off threshold in the inspector)

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetAxisDownUp("Vertical") ) {
            Jump();
        }
    }
}
```

## GetAxisDownRight

# ETCInput.GetAxisDownRight

```
public static bool GetAxisDownRight(string: buttonName)
```

### Description

Returns true during the frame the user move right the axis identified by axisName.

For Joystick the value of its axis must be greater than axis threshold (On / Off threshold in the inspector)

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetAxisDownRight("Horizontal") ) {
            MoveOneStepRight();
        }
    }
}
```

## GetAxisDownDown

# ETCInput.GetAxisDownDown

```
public static bool GetAxisDownDown(string: buttonName)
```

### Description

Returns true during the frame the user move down the axis identified by axisName.

For Joystick the value of its axis must be > axis threshold (On / Off threshold in the inspector)

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetAxisDownDown("Vertical") ) {
            Crush();
        }
    }
}
```

## GetAxisDownLeft

# ETCInput.GetAxisDownLeft

```
public static bool GetAxisDownLeft(string: buttonName)
```

## Description

Returns true during the frame the user move left the axis identified by axisName.

For Joystick the value of its axis must be greater than axis threshold (On / Off threshold in the inspector)

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetAxisDownLeft("Horizontal") ) {
            MoveOneStepLeft();
        }
    }
}
```

## GetAxisPressedUp

# ETCInput.GetAxisPressedUp

```
public static bool GetAxisPressedUp(string: buttonName)
```

### Description

Returns true while the axis identified by axisName is held in up.

For Joystick the value of its axis must be > axis threshold one time (On / Off threshold in the inspector)

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetAxisPressedUp("Vertical") ) {
            transform.Translate(Vector3.forward * Time.deltaTime);
        }
    }
}
```

## GetAxisPressedRight

# ETCInput.GetAxisPressedRight

```
public static bool GetAxisPressedRight(string: buttonName)
```

### Description

Returns true while the axis identified by axisName is held in right.

For Joystick the value of its axis must be > axis threshold one time (On / Off threshold in the inspector)

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetAxisPressedUp("Horizontal")) {
            transform.Translate(Vector3.right * Time.deltaTime);
        }
    }
}
```

## GetAxisPressedDown

# ETCInput.GetAxisPressedDown

```
public static bool GetAxisPressedDown(string: buttonName)
```

### Description

Returns true while the axis identified by axisName is held in down.

For Joystick the value of its axis must be > axis threshold one time (On / Off threshold in the inspector)

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetAxisPressedDown("Vertical") ) {
            transform.Translate(Vector3.down * Time.deltaTime);
        }
    }
}
```

## GetAxisPressedLeft

# ETCInput.GetAxisPressedLeft

```
public static bool GetAxisPressedLeft(string: buttonName)
```

### Description

Returns true while the axis identified by axisName is held in left.

For Joystick the value of its axis must be > axis threshold one time (On / Off threshold in the inspector)

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetAxisPressedUp("Horizontal")) {
            transform.Translate(Vector3.left * Time.deltaTime);
        }
    }
}
```

## Static functions for axes properties

# ETCInput

## Description

Interface into the EasyTouch Controls Input system.

Use this class to read/write the axes, buttons, controls.

Axis names are configurable in the inspector and must be unique. The buttons don't have axes, is the name of the button that will be taken into account.

## Static functions for axes properties

- [SetAxisEnabled](#) : Set the axis identified by axisName enabled or not.
- [GetAxisEnabled](#) : Return true if the axis identified by axisName is enabled.
- [SetAxisInverted](#) : Set the axis identified by axisName inverted or not.
- [GetAxisInverted](#) : Return true if the axis identified by axisName is inverted.
- [SetAxisDeadValue](#) : Set the dead value of the axis identified by axisName.
- [GetAxisDeadValue](#) : Return the dead value of the axis identified by axisName.
- [SetAxisSensitivity](#) : Set the sensitivity value of the axis identified by axisName.
- [GetAxisSensitivity](#) : Return the sensitivity value of the axis identified by axisName.
- [SetAxisThreshold](#) : Set the threshold value of the axis identified by axisName.
- [GetAxisThreshold](#) : Return the threshold value of the axis identified by axisName.
- [SetAxisInertia](#) : Set the inertia enabled or not on the axis identified by axisName.
- [GetAxisInertia](#) : Return true if the axis identified by axisName has inertia enabled.
- [SetAxisInertiaSpeed](#) : Set the inertia value of the axis identified by axisName.
- [GetAxisInertiaSpeed](#) : Return the inertia value of the axis identified by axisName.
- [SetAxisInertiaThreshold](#) :Set the inertia threshold value of the axis identified by axisName.
- [GetAxisInertiaThreshold](#) : Return the inertia threshold value of the axis identified by axisName.
- [SetAxisAutoStabilization](#): Set the auto-stabilization enabled or not on the axis identified by axisName.
- [GetAxisAutoStabilization](#): Return true if the axis identified by axisName has auto-stabilization enabled.
- [SetAxisAutoStabilizationSpeed](#) : Set the auto-stabilization speed value of the axis identified by axisName.
- [GetAxisAutoStabilizationSpeed](#) : Return the auto-stabilization speed value of the axis identified by

axisName.

[SetAxisAutoStabilizationThreshold](#): Set the auto-stabilization threshold value of the axis identified by axisName.

[GetAxisAutoStabilizationThreshold](#): Return the auto-stabilization threshold value of the axis identified by axisName.

[SetAxisClampRotation](#) : Set the clamp rotation enabled or not on the axis identified by axisName.

[GetAxisClampRotation](#) : Return true if the axis identified by axisName has clamp rotation enabled.

[SetAxisClampRotationValue](#) : Set the min & max clamp rotation value on the axis identified by axisName.

[SetAxisClampRotationMinValue](#) : Set the min clamp rotation value on the axis identified by axisName.

[GetAxisClampRotationMinValue](#) : Return the min clamp rotation value on the axis identified by axisName.

[SetAxisClampRotationMaxValue](#) : Set the max clamp rotation value on the axis identified by axisName.

[GetAxisClampRotationMaxValue](#) : Return the max clamp rotation value on the axis identified by axisName.

[SetAxisDirecTransform](#) : Set the transform direction action on the axis identified by axisName.

[GetAxisDirectTransform](#) : Return the transform direction action on the axis identified by axisName.

[SetAxisDirectAction](#) : Set the direction action on the axis identified by axisName.

[GetAxisDirectAction](#) : Return the direction action on the axis identified by axisName.

[SetAxisAffectedAxis](#) : Set the axis affected by the direct action on the axis identified by axisName.

[GetAxisAffectedAxis](#) : Return the axis affected by the direct action on the axis identified by axisName.

## SetAxisEnabled

# ETCInput.SetAxisEnabled

public static void **SetAxisEnabled**(string: axisName, bool value)

## Description

Set the axis identified by axisName enabled or not, relative to value parameter.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisEnabled("Vertical", true);
    }
}
```

## GetAxisEnabled

# ETCInput.GetAxisEnabled

```
public static bool GetAxisEnabled(string: axisName)
```

## Description

Return true if the axis identified by axisName is enabled.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetAxisEnabled("Horizontal")) {
            Debug.Log( "Axis Horizontal is enabled");
        }
    }
}
```

## SetAxisInverted

# ETCInput.SetAxisInverted

public static void **SetAxisInverted**(string: axisName, bool value)

## Description

Set the axis identified by axisName inverted or not.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisInverted("Vertical",true);
    }
}
```

## GetAxisInverted

# ETCInput.GetAxisInverted

```
public static bool GetAxisInverted(string: axisName)
```

## Description

Return true if the axis identified by axisName is inverted.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetAxisInverted("Horizontal")) {
            Debug.Log( "Axis Horizontal is inverted");
        }
    }
}
```

## SetAxisDeadValue

# ETCInput.SetAxisDeadValue

```
public static void SetAxisDeadValue(string: axisName, float value)
```

### Description

Set the dead value of the axis identified by axisName.

This value corresponds to a dead zone in relative value (0..1), where the axis will not be considered in motion (only for joystick)

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisDeadValue("Vertical", 0.2f);
    }
}
```

## GetAxisDeadValue

# ETCInput.GetAxisDeadValue

```
public static float GetAxisDeadValue(string: axisName)
```

## Description

Return the dead value of the axis identified by axisName.

This value corresponds to a dead zone in relative value (0..1), where the axis will not be considered in motion (only for joystick)

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        float deadV = ETCInput.GetAxisDeadValue("Horizontal");
        Debug.Log( deadV);
    }
}
```

## SetAxisSensitivity

# ETCInput.SetAxisSensitivity

```
public static void SetAxisSensitivity(string: axisName, float value)
```

## Description

Set the sensitivity value of the axis identified by axisName.

This value is used by direct mode to operate the operation, and in the calculation of value returned by [ETCInput.GetAxisSpeed](#).

Axis Sensitivity = Axis speed for Joystick and DPad on inspector.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisSensitivity("Vertical",50f);
    }
}
```

## GetAxisSensitivity

# ETCInput.GetAxisSensitivity

```
public static float GetAxisSensitivity(string: axisName)
```

## Description

Return the sensitivity value of the axis identified by axisName.

This value is used by direct mode to operate the operation, and in the calculation of value returned by [ETCInput.GetAxisSpeed](#).

Axis Sensitivity = Axis speed for Joystick and DPad on inspector.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        float sensitivity = ETCInput.GetAxisSensitivity("Horizontal");
        Debug.Log( sensitivity );
    }
}
```

## SetAxisThreshold

# ETCInput.SetAxisThreshold

```
public static void SetAxisThreshold(string: axisName, float value)
```

## Description

Set the threshold value of the axis identified by axisName.

This value is used to determine the threshold when the axis will be considered down for the first time.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisThreshold("Vertical", 0.2f);
    }
}
```

## GetAxisThreshold

# ETCInput.GetAxisThreshold

```
public static float GetAxisThreshold(string: axisName)
```

## Description

Return the threshold value of the axis identified by axisName.

This value is used to determine the threshold when the axis will be considered down for the first time.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        float threshold = ETCInput.GetAxisThreshold("Horizontal");
        Debug.Log( threshold );
    }
}
```

## SetAxisInertia

# ETCInput.SetAxisInertia

public static void **SetAxisInertia**(string: axisName, bool value)

## Description

Set the inertia enabled or not on the axis identified by axisName.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisInertia("Vertical",true);
    }
}
```

## GetAxisInertia

# ETCInput.GetAxisInertia

```
public static bool GetAxisInertia(string: axisName)
```

## Description

Return true if the axis identified by axisName has inertia enabled.

This value is used to determine the threshold when the axis will be considered down for the first time.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if ( ETCInput.GetAxisInertia("Horizontal")){
            Debug.Log( "Inertia is enabled" );
        }
    }
}
```

## SetAxisInertiaSpeed

# ETCInput.SetAxisInertiaSpeed

public static void **SetAxisInertiaSpeed**(string: axisName, float value)

### Description

Set the inertia value of the axis identified by axisName.

The higher the value is, the greater the inertia effect is important.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisInertiaSpeed("Vertical",200);
    }
}
```

## GetAxisInertiaSpeed

# ETCInput.GetAxisInertiaSpeed

```
public static float GetAxisInertiaSpeed(string: axisName)
```

## Description

Return the inertia value of the axis identified by axisName.

The higher the value is, the greater the inertia effect is important.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        float inertiaSpeed = ETCInput.GetAxisInertiaSpeed("Horizontal");
        Debug.Log( inertiaSpeed );
    }
}
```

## SetAxisInertiaThreshold

# ETCInput.SetAxisInertiaThreshold

```
public static void SetAxisInertiaThresold(string: axisName, float value)
```

## Description

Set the inertia threshold value of the axis identified by axisName.

This value allows to determine the threshold below which the axis will be reset to the 0 position when inertia is enabled.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisInertiaThreshold("Vertical",0.1f);
    }
}
```

## GetAxisInertiaThreshold

# ETCInput.GetAxisInertiaThreshold

```
public static float GetAxisInertiaThreshold(string: axisName)
```

## Description

Return the inertia threshold value of the axis identified by axisName.

This value allows to determine the threshold below which the axis will be reset to the 0 position when inertia is enabled.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        float inertiaThreshold = ETCInput.GetAxisInertiaThreshold("Horizontal");
        Debug.Log( inertiaThreshold );
    }
}
```

## SetAxisAutoStabilization

# ETCInput.SetAxisAutoStabilization

```
public static void SetAxisAutoStabilization(string: axisName, bool value)
```

## Description

Set the auto-stabilization enabled or not on the axis identified by axisName.

Self-stabilization is take into account only in the direct mode with an action on Local Rotation.It allows to return the object to its original rotation.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisAutoStabilization("Vertical",true);
    }
}
```

## GetAxisAutoStabilization

# ETCInput.GetAxisAutoStabilization

```
public static bool GetAxisAutoStabilization(string: axisName)
```

## Description

Return true if the axis identified by axisName has auto-stabilization enabled.

Self-stabilization is take into account only in the direct mode with an action on Local Rotation.It allows to return the object to its original rotation.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if ( ETCInput.GetAxisAutoStabilization("Horizontal")){
            Debug.Log("AutoStabilization is enabled ");
        }
    }
}
```

## SetAxisAutoStabilizationSpeed

# ETCInput.SetAxisAutoStabilizationSpeed

```
public static void SetAxisAutoStabilization(string: axisName, float value)
```

## Description

Set the auto-stabilization speed value of the axis identified by axisName.

Self-stabilization is take into account only in the direct mode with an action on Local Rotation.It allows to return the object to its original rotation.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisAutoStabilizationSpeed("Vertical",200);
    }
}
```

## GetAxisAutoStabilizationSpeed

# ETCInput.GetAxisAutoStabilizationSpeed

```
public static float GetAxisAutoStabilizationSpeed(string: axisName)
```

## Description

Return the auto-stabilization speed value of the axis identified by axisName.

Self-stabilization is take into account only in the direct mode with an action on Local Rotation.It allows to return the object to its original rotation.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        float speed = ETCInput.GetAxisAutoStabilizationSpeed("Horizontal");
        Debug.Log(speed );
    }
}
```

## SetAxisAutoStabilizationThreshold

# ETCInput.SetAxisAutoStabilizationThreshold

```
public static void SetAxisAutoStabilizationThreshold(string: axisName, float value)
```

### Description

Set the auto-stabilization threshold value of the axis identified by axisName.

This value allows to determine the threshold below which the axis will be reset to the 0 position when auto-stabilization is enabled.

Self-stabilization is take into account only in the direct mode with an action on Local Rotation.It allows to return the object to its original rotation.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisAutoStabilizationThreshold("Vertical",0.1f);
    }
}
```

## GetAxisAutoStabilizationThreshold

# ETCInput.GetAxisAutoStabilizationThreshold

```
public static float GetAxisAutoStabilizationThreshold(string: axisName)
```

## Description

Return the auto-stabilization threshold value of the axis identified by axisName..

Self-stabilization is take into account only in the direct mode with an action on Local Rotation.It allows to return the object to its original rotation.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        float threshold = ETCInput.GetAxisAutoStabilizationThreshold("Horizontal");
        Debug.Log(Speed );
    }
}
```

## SetAxisClampRotation

# ETCInput.SetAxisClampRotation

```
public static void SetAxisClampRotation(string: axisName, bool value)
```

## Description

Set the clamp rotation enabled or not on the axis identified by axisName.

ClampRotation is take into account only in the direct mode with an action on Local Rotation.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisClampRotation("Vertical",true);
    }
}
```

## GetAxisClampRotation

# ETCInput.GetAxisClampRotation

```
public static bool GetAxisClampRotation(string: axisName)
```

## Description

Return true if the axis identified by axisName has clamp rotation enabled.

ClampRotation is take into account only in the direct mode with an action on Local Rotation.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if ( ETCInput.GetAxisClampRotation("Horizontal")){
            Debug.Log("ClampRotation is enabled ");
        }
    }
}
```

## SetAxisClampRotationValue

# ETCInput.SetAxisClampRotationValue

```
public static void SetAxisClampRotationValue(string: axisName, float min , float max)
```

### Description

Set the min & max clamp rotation value on the axis identified by axisName.

#### Horizontal Axis

min = limit angle to the left

max = limit angle to the right

#### VerticalAxis

min = limit angle up

max = limit angle down

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisClampRotationValue("Vertical",60,15);
    }
}
```

## SetAxisClampRotationMinValue

# ETCInput.SetAxisClampRotationMinValue

```
public static void SetAxisClampRotationMinValue(string: axisName, float value)
```

### Description

Set the min rotation value on the axis identified by axisName.

#### Horizontal Axis

min = limit angle to the left

#### Vertical Axis

min = limit angle up

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisClampRotationMinValue("Vertical",60);
    }
}
```

## GetAxisClampRotationMinValue

# ETCInput.GetAxisClampRotationMinValue

```
public static float GetAxisClampRotationMinValue(string: axisName)
```

## Description

Return the min clamp rotation value on the axis identified by axisName.

### Horizontal Axis

min = limit angle to the left

### Vertical Axis

min = limit angle up

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        float min = ETCInput.GetAxisClampRotationMinValue("Horizontal");
        Debug.Log(min );
    }
}
```

## SetAxisClampRotationMaxValue

# ETCInput.SetAxisClampRotationMaxValue

```
public static void SetAxisClampRotationMaxValue(string: axisName, float value)
```

### Description

Set the max rotation value on the axis identified by axisName.

#### Horizontal Axis

max = limit angle to the right

#### Vertical Axis

max = limit angle down

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisClampRotationMaxValue("Vertical",60);
    }
}
```

## GetAxisClampRotationMaxValue

# ETCInput.GetAxisClampRotationMaxValue

```
public static float GetAxisClampRotationMaxValue(string: axisName)
```

## Description

Return the max clamp rotation value on the axis identified by axisName.

### Horizontal Axis

max = limit angle to the right

### Vertical Axis

max = limit angle down

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        float max = ETCInput.GetAxisClampRotationMaxValue("Horizontal");
        Debug.Log(max );
    }
}
```

## SetAxisDirectTransform

# ETCInput.SetAxisDirectTransform

```
public static void SetAxisDirectTransform(string: axisName, Transform value)
```

## Description

Set the transform direction action on the axis identified by axisName.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    public GameObject object2Move;

    void Start() {
        ETCInput.SetAxisDirectTransform("Vertical",object2Move.transform);
    }
}
```

## GetAxisDirectTransform

# ETCInput.GetAxisDirectTransform

```
public static Transform GetAxisDirectTransform(string: axisName)
```

## Description

Return the transform direction action on the axis identified by axisName.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        Transform obj2move = ETCInput.GetAxisDirectTransform("Horizontal");
        Debug.Log( obj2move.name );
    }
}
```

## SetAxisDirectAction

# ETCInput.SetAxisDirectAction

public static void **SetAxisDirectAction**(string: axisName, [ETCAxis.DirectAction](#) value)

## Description

Set the direction action on the axis identified by axisName.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisDirectAction("Vertical",ETCAxis.DirectAction.RelativeForce);
    }
}
```

## GetAxisDirectAction

# ETCInput.GetAxisDirectAction

public static [ETCAxis.DirectAction](#) GetAxisDirectAction(string: axisName)

## Description

Return the direction action on the axis identified by axisName.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetAxisDirectAction("Horizontal") == ETCAxis.DirectAction.Rotate){
            Debug.Log( "Rotation" );
        }
    }
}
```

## SetAxisAffectedAxis

# ETCInput.SetAxisAffectedAxis

public static void **SetAxisAffectedAxis**(string: axisName, [ETCAxis.AxisInfluenced](#) value)

## Description

Set the axis affected by the direct action on the axis identified by axisName.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Start() {
        ETCInput.SetAxisAffectedAxis("Vertical",ETCAxis.AxisInfluenced.X);
    }
}
```

## GetAxisAffectedAxis

# ETCInput.GetAxisAffectedAxis

public static [ETCAxis.AxisInfluenced](#) GetAxisAffectedAxis(string: axisName)

## Description

Return the axis affected by the direct action on the axis identified by axisName.

```
using UnityEngine;
using System.Collections;

public class ExampleClass : MonoBehaviour {

    void Update() {
        if (ETCInput.GetAxisAffectedAxis("Horizontal") == ETCAxis.AxisInfluenced.X){
            Debug.Log( "Direction action on X axis" );
        }
    }
}
```

## Enumerations

---

### DirectAction

## ETCAxis.DirectAction

### Description

Identified the type of action that will be applied to the object that is in direct mode

### Variables

Rotate

RotateLocal

Translate

TranslateLocal

Scale

Force

RelativeForce

Torque

RelativeTorque

### DPadAxis

## ETCBase.DPadAxis

### Description

Identified the axes count for a DPad

### Variables

Two\_Axis

Four\_Axis

## AxisInfluenced

# ETCAxis.AxisInfluenced

### Description

Identified the axis of action that will be applied to the object that is in direct mode.

### Variables

X

Y

Z